

# DAMAR® Installation Instructions

## H Track Systems

### 37631D, 37640D floating canopy

#### **SAFETY INSTRUCTION**

- Read all of these instructions before installing the track system.
- Turn off power at main switch before installing or modifying the system.
- Do not install within six inches of any curtain or combustible materials.
- Do not install less than 5 feet above a floor.
- Do not install in damp or wet locations.
- Do not install concealed or extended through building walls.
- Do not attempt to energize anything other than a track light fixture.
- Do not connect a track to more than one branch circuit. Although track light systems may seem to operate acceptably, a dangerous overload of the neutral may occur and result in a risk of fire.
- Check with a qualified electrician before wiring.
- All installation shall be in accordance with NEC and all local codes.
- Save these installation instructions and refer to them when additions or changes to the track configuration are made.

#### **Electrical Feed Installation from a Junction Box with Floating Canopy**

1. Before starting any installation, make sure to turn off the power supply.
2. Take the electrical adapter off the mounting plate.
3. Attach the mounting plate to the junction box using the provided slotted holes.
4. Hold the track against the ceiling and mark the locations of the mounting holes. Adjust the position of the mounting plate accordingly, ensuring that the screw tabs are facing downward.
5. Follow the specific mounting instructions provided for your track system to secure it to the ceiling.
6. Fasten the track to the mounting plate and tighten the screws on both sides to ensure stability.
7. Place the electrical adapter into the track directly beneath the junction box. Route the wires along the side of the track and into the junction box.
8. Connect the neutral (white) and hot (black) wires from the ceiling to their corresponding wires from the track adapter.
9. Attach the ground wire from the ceiling to the green grounding wire from the adapter.
10. Neatly tuck any excess wiring back into the junction box.
11. Secure the canopy cover back in place using screws.

