
## Wiring Diagram



## Twist-Lock Photocell Sensor Install (Optional Accessory)

- 1. Remove shorting cap by twisting to the left and removing.
- 2. Replace with twist-lock Photocell sensor by inserting keyed tab into keyed hole on socket and twisting to the right