


# LED SHOEBOX 180-210-240W



## Specifications

Item	- 36970A
Model	- LED SHOEBOX 180-210-240W
Fixture Type	- LED
Input Voltage	- 120-277VAC 50/60 Hz
Watts	- 180/210/240W Selectable
PF	- ≥0.9
Dimmable	- Yes, 0-10V (Used By Internal Wattage Switch)
Beam Angle	- Type III 140°H X 100°V
Color Temp	- 3/4/5K Selectable
CRI	- 70
Lumen	- 3K 180W = 22,500lm 210W = 26,250lm 240W = 30,200lm
	- 4K 180W = 24,660lm 210W = 28,770lm 240W = 33,000lm
	- 5K 180W = 24,480lm 210W = 28,560lm 240W = 32,800lm
Photocell	- Optional (36969B)
Average Life Hours	- 50,000
Location Rating	- Wet Locations (IP65)
Ambient Operating Temp	- -40°F to 122°F
Surge Protection	- 6KV
Length	- 29.75"
Width	- 13.125"
Height	- 3.0"
EPA	- 2.15 f <sup>2</sup>

## Caution

- This fixture must be wired in accordance with the National Electrical Code and applicable local ordinance. Proper grounding is required to insure personal safety. Carefully observe grounding procedure under installation section.
- Make certain power is OFF before starting installation or attempting any maintenance. Risk of fire/electric shock. If not qualified, consult an electrician.
- Disconnect power at fuse or circuit breaker before installing or servicing
- Risk OF BURN--Disconnect power and allow fixture to cool before servicing.
- RISK OF PERSONAL INJURY--Fixture may become damaged and/or unstable if not installed properly. Tighten all fixture components to their recommended torque values.


**\*\*NOTE - TURN OFF POWER BEFORE ADJUSTING WATTAGE OR COLOR TEMPERATURE\*\***



Dimmable




## SPECIAL FUNCTIONS INSTRUCTION:



### Color tunable instruction

- 1, The color temperature of the lamp turns to 3000K when the switch is set to 3K ;
- 2, The color temperature of the lamp turns to 4000K when the switch is set to 4K ;
- 3, The color temperature of the lamp turns to 5000K when the switch is set to 5K ;

Note: Please turn off the power before adjusting the color temperature.



### Wattage adjustable instruction

Turn the wattage adjustable knob to a certain wattage gear, the power of the lamp will change to the corresponding wattage.

Adjustable wattage range 180,210,240 watts

Note: Please turn off the power before adjusting the wattage.

## Wiring Diagram

