Smart RGBW LED String Light App Control

Download Free APP









Available on the App Store



Step 1: Download APP Download the Smart Life APP from App Store or Google Play.





Step 1: Download APP Download the Tuya Smart APP from App Store or Google Play.





Step 2: Register

1. Enter your email address.



2. Enter the verification code and create a password.



3.Create a password and Log in the App.




4. Please enable the Smart Life APPto get your Bluetooth while using it.



Step 3: Plug in

Plug Smart String Lights into any standard outlet.



Notes:

- 1. After power on, the light bulbs will automatically enter the connecting state (fast blinking);
- 2. If there is no connection after 3 minutes, the indicator lights will remain on. If you want to add a device at this time, you need to press and hold the power button on the controller for about 5 to 7 seconds until the lights blink rapidly.

∨Auto Scan

Select "Add Device" or click "+" at the top right corner of the homepage.



- Please enable the Smart Life APP to get your Access location while using the APP.
- Fill in your 2.4GHz network name and password.
- Allow Smart Life APP to enable Bluetooth.



∨Auto Scan

- The device in the connecting state will be displayed at the left of the page.
- Click "Next" and confirm your network again.



∨Auto Scan

- The product starts to connect until it displays 100% complete.
- After you edit the product name and save it, click "DONE" at the top right.





Please keep the router, mobile phone, and product as close as possible to ensure a good reception signal.

Congratulation!

Now you can use Smart Life APP to control your string lights.



If your device is not automatically discovered, you can add manually.

Step 4: Add Device

✓ Add Manually ✓ EZ Mode

Select "Add Device" or click "+" at the top right corner of the homepage. Choose Lighting - String Lights -String Light (BLE+Wi-Fi) from the device list.





- ✓ Add Manually
 ✓ EZ Mode
- Select "EZ Mode" on the upper right corner.
- If the light is not blinking rapidly automatically, please long press the power button on the controller for about 5 to 7 seconds, until the string lights blink rapidly.
- And click "Confirm the light is blinking rapidly".



 Follow the prompts on the interface to fll in your 2.4GHz Wi-Fi name and password, and click "Next".



✓ Add Manually ✓ EZ Mode

The device enters the state of connecting and distributing the network, then wait for the completion of adding the device,



Having difficulty pairing the string lights with EZ Mode? You could try the "AP Mode".

AP Mode: If you cannot add a device with EZ Mode, or you are not sure whether the network is 2.4GHz, please try "AP Mode".

Step 4: Add Device

- **∨Add** Manually
 - ✓ AP Mode
- •Select "Add Device" or click "+" at the top right corner of the homepage.
- Choose Lighting String Lights -String Light (BLE+Wi-Fi) from the device list.





- Select "AP Mode" on the upper right corner.
- Long-press the power button on the controller for a bout 5-7 seconds until the lights blink rapidly.
- Under the blinking state, long-press the power button for about 5-7 seconds until the lights turn to slow blinking (blink 1 time every 3 seconds). If they still blinkrapidly,repeats this step until they blink slowly.

 Click "Confirm the light is blinking slowly".





∨ Add Manually

∨ AP Mode

- Follow the prompts on the interface to fll in your 2.4GHz Wi-Fi name and password, and click "Next".
- Select the hotspot "SamrtLife-XXXX" in the available network to connect. Please confirm that the hotspot network is connected successfuly, then go back to the APP to start the connection.





✓ Add Manually ✓ AP Mode

The device enters the state of connecting and distributing the network!
 After the product is initialized, you can use Smart Life APP to control the string lights.



Besides "EZ Mode" and "AP Mode", you can use "Bluetooth Mode" as well.

Step 4: Add Device

- **∨** Add Manually
 - → Bluetooth
- Under Bluetooth Mode, please make sure you fill in your 2.4GHz network name and password already. And click "Confirm the light has flashed or breathed".
- Allow Smart Life APP to enable Bluetooth.





- **∨Add** Manually
 - ∨ Bluetooth
- After 1 device is found, click "+".



 Confirm your network and click "Next".



- **∨** Add Manually
 - ∨ Bluetooth

When added 1 device sucessfully, Click "Next".



Congratulation!

Now you can use Smart Life APP to control your string lights.




White Mode

Color Temperature

Rotate the white wheel to adjust the color temperature of the white lights from 2700k to 6000k.

Brightness

Slide the "Brightness" bar to adjust the brightness of the string lights, then you can freely brighten or dim the lights.



Color Changing Mode

Color Wheel

Rotate the color wheel to adjust the color of the lights from a broad spectrum of colors.

Default Color

Or click the round color icons to choose a default color. You can also click the "+" to add a default color.

Color Temperature

Slide the "Saturation" bar to adjust the color temperature of the string lights from cool to white.

Brightness

Slide the "Brightness" bar to adjust the brightness of the string lights, then you can freely brighten or dim the lights.



Scenes

Smart Life APP has a scene selection function. Press the scene button to enter the scene selection interface. You can choose your favorite scenes from 9 default scenes.



Pick 2

Hold the "Pick 2" button for 2 seconds to activate the customized color scene. Pick two colors and customize their brightness and saturation as you like.



Schedule

The App is free to add and set the working time of the Smart String Light, which can be turned on and off freely according to the set time.

Select the time to repeat the setting within a week.



Define whether the set time is the beginning or the end of the work.

