


USE AND CARE INSTRUCTIONS:

1. When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
2. If the product is placed on a tree, the tree should be well secured and stable.
3. Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
4. When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
5. When not in use, store neatly in a cool, dry location protected from sunlight.

USER SERVICING INSTRUCTIONS: SAFETY PLUG WITH REPLACEABLE FUSE:

Risk of fire. Do not replace attached plug. Discard product if the attached plug is damaged. Product contains a safety device (fuse). Product should not be used if safety device (fuse) is removed.

1. Always unplug product from the receptacle or other outlet device before installing or replacing fuse.
2. Grasp plug to remove from receptacle or other outlet device. Do not unplug by pulling on cord.
3. To open fuse cover: Slide open fuse access cover on top of plug, towards the blades.
4. Remove fuses carefully by turning plug over.
5. Risk of fire. Replace fuse only with 3 Amp, 120 Volt fuse (provided with product).
6. To close the fuse cover, slide back into place. Check to verify the fuse access cover on top of plug is securely closed.



Made In China