

Brand	Input	Item	Start Mode	Output	Test Result
DAMAR	120V-277V	01688B EL232-120/277HF	Instant Start	2-lamp	YES
	120V-277V	03654C EL332-120/277HF	Instant Start	3-lamp	YES
	120V-277V	03093B EL432-120/277HF	Instant Start	4-lamp	YES
GE		GE132-MV-N	Instant Start	1-lamp	No Test
	120V	GEM1FC8T9RS120/2-DIY	Magnetic Ballast	1-lamp	NO
	120V	GEM120PH120/2-DIY	Magnetic Ballast	1-lamp	NO
	120V	GEM220TS120/2-DIY	Magnetic Ballast	2-lamp	NO
	120V-277V	GE232MAX-G-H	Instant Start	2-lamp	YES
	120V-277V	GE240PSMVN-DIYB (T12)	Programmed Start	2-lamp	YES
		GE132-MV-PS-L	Instant Start	1-lamp	No Test
		GE132MAXP-L/ULTRA	Instant Start	1-lamp	No Test
		GE132MAXP-N/ULTRA	Instant Start	1-lamp	No Test
		GE132MAX-L/ULTRA	Instant Start	1-lamp	No Test
		GE132MAX-N/ULTRA	Instant Start	1-lamp	No Test
		GE132MAX-H/ULTRA	Instant Start	1-lamp	No Test
		GE232 MA	Instant Start	2-lamp	YES
		GE232MV-N-DIY	Instant Start	2-lamp	YES
		GE232MAX-G-N	Instant Start	2-lamp	YES
		GE232MAX-G-N-DIYB	Instant Start	2-lamp	YES
		GE232-120-RES	Instant Start	2-lamp	YES
		GE232-120RESDIYB	Instant Start	2-lamp	YES
		GE232MAX-L/ULTRA	Instant Start	2-lamp	YES
		GE232MAX-N/ULTRA	Instant Start	2-lamp	YES
		GE232MAX-H/ULTRA	Instant Start	2-lamp	YES
		GEM220TS120/2-DIY	Magnetic Ballast	2-lamp	NO
		GE-232-MV-PS-N	Programmed Start	2-lamp	No Test
		GE259MV-N	Instant Start	2-lamp	YES
		GE332MAX-L	Instant Start	3-lamp	YES
	120V-277V	GE332MAX-H/ULTRA	Instant Start	3-lamp	YES
	120-277V	GE332MAX-G-H	Instant Start	3-lamp	YES
		GE332MV-L	Instant Start	3-lamp	YES
		GE332MAX-L/ULTRA	Instant Start	3-lamp	YES
		GE332MAX-N/ULTRA	Instant Start	3-lamp	YES
		GE432MV-N-DIY	Instant Start	4-lamp	No Test
	120-277V	GE432MAX-G-N-DIYB	Instant Start	4-lamp	YES
		GE432MAX-G-N	Instant Start	4-lamp	YES
		GE432MAXP-H	Instant Start	4-lamp	No Test
		GE432MAX347-N	Instant Start	4-lamp	YES
		GE432MAXP-N/ULTRA	Instant Start	4-lamp	NO
		GE432-120RESDIY	Instant Start	4-lamp	No Test
		GE432-120RESDIYB	Instant Start	4-lamp	No Test
		GE432MAX-H/ULTRA	Instant Start	4-lamp	NO

PHILIPS Advance		ICN-1P32-N	Instant Start	1-lamp	No Test
		IOPA-1P32-N	Instant Start	1-lamp	No Test
		ICN-2P32-N	Instant Start	2-lamp	YES
		REB-2P32-SC	Instant Start	2-lamp	YES
		IOP-2P32HL-SC	Instant Start	2-lamp	YES
		IOPA-2P32HL-N	Instant Start	2-lamp	YES
		IOPA-2P32HL-SC	Instant Start	2-lamp	YES
		IOPA-2P32-N	Instant Start	2-lamp	YES
		IOPA-2P32-LW-N	Instant Start	2-lamp	YES
		IDA-2S32-SC	Programmed Start	2-lamp	No Test
		REB-2P32-SC	Instant Start	2-lamp	YES
		GOPA-2P32-SC	Instant Start	2-lamp	YES
		VEL-2P32-SC	Instant Start	2-lamp	YES
	120-277V	IOPA-3P32-N	Instant Start	3-lamp	YES
		IOPA-3P32HL-SC	Instant Start	3-lamp	YES
		ICN-4P32-N	Instant Start	4-lamp	YES
		REB-4P32-SC	Instant Start	4-lamp	No Test
	120V-277V	IOPA-4P32-N	Instant Start	4-lamp	No Test
		IOPA-4P32-LW-N	Instant Start	4-lamp	No Test
	120V-277V	IOPA-4P32-SC	Instant Start	4-lamp	No Test
	120V-277V	IOPA-4P32-HL	Instant Start	4-lamp	YES
	347V	GOPA-4P32-SC	Instant Start	4-lamp	YES
	347V	GOPA-3P32-SC	Instant Start	3-lamp	YES
OSRAM/ SYLVANIA		IOPA-4P32-LW-SC	Instant Start	4-lamp	NG
		VEL-4P32-SC	Instant Start	4-lamp	NG
		QTP 1X32T8/UNV ISN-SC	Instant Start	1-lamp	No Test
		QHE 1X32T8/UNV ISH HT SC	Instant Start	1-lamp	No Test
		QHE 1X32T8/UNV ISL-SC	Instant Start	1-lamp	No Test
		QHE 1X32T8/UNV ISN-SC	Instant Start	1-lamp	No Test
		QHE 1X32T8/UNV ISH SC	Instant Start	1-lamp	No Test
		QHE 1X32T8/UNV PSN-MC	Programmed Start	1-lamp	No Test
		QHE 2X32T8/UNV ISL-SC	Instant Start	2-lamp	YES
		QHE 2X32T8/UNV ISN-SC	Instant Start	2-lamp	YES
		QHE 2X32T8/UNV ISH-SC	Instant Start	2-lamp	YES
		QHE 2X32T8/UNV ISH HT-SC	Instant Start	2-lamp	YES
	120V-277V	QHE 2x32T8/UNV PSN-MC	Programmed Rapid Start	2-lamp	No Test
		QHE 2X32T8/UNV DIM-TC	Programmed Start	2-lamp	YES
		QTP 2X32T8/UNV ISN-SC	Instant Start	2-lamp	YES
		QHE 3X32T8/UNV ISL-SC	Instant Start	3-lamp	YES
		QTP 3*32T8/UNV ISN-SC	Instant Start	3-lamp	YES
		QHE 3x32T8/UNV ISN-SC	Instant Start	3-lamp	YES
		QHE 3x32T8/UNV PSN-SC	Programmed Start	3-lamp	No Test
		QHE 3x32T8/UNV PSH-HT-SC	Programmed Start	3-lamp	No Test
	120V-277V	QTP 4X32T8/UNV ISN-SC	Instant Start	4-lamp	YES
		QHE 4x32T8/UNV ISL-SC	Instant Start	4-lamp	YES
		QHE 4X32T8/UNV ISN-SC	Instant Start	4-lamp	YES
		QHE 4x32T8/UNV ISL-SC	Instant Start	4-lamp	YES
		QHE 4x32T8/UNV PSN-SC	Programmed Start	4-lamp	YES
		QHE 4X32T8/UNV ISH	Instant Start	4-lamp	YES
		QHE 4x32T8/347 ISN-SC	Instant Start	4-lamp	YES

UNIVERSAL		B132IUNVEL-A	Instant Start	1-lamp	No Test
		B132IUNVHP-N	Instant Start	1-lamp	No Test
		B132IUNVHP-B	Instant Start	1-lamp	No Test
		B232IUNVHE-N	Instant Start	2-lamp	YES
	347V	B232I347HP-A	Instant Start	2-lamp	YES
		B232IUNVEL-N	Instant Start	2-lamp	YES
		B232IUNVHP-N	Instant Start	2-lamp	YES
	120V-277V	B232IUNVHEH-A	Instant Start	2-lamp	YES
		B232PUNVHE-B	Programmed Start	2-lamp	No Test
		B332IUNVHE-A	Instant Start	3-lamp	YES
		B432IUNVHE-A	Instant Start	4-lamp	YES
		B432IUNVEL-A	Instant Start	4-lamp	YES
		B432I347HP	Instant Start	4-lamp	YES
		B432I347HPL	Instant Start	4-lamp	YES
ULTRASAVE		ET232120M	Instant Start	2-lamp	YES
SUNPARK		120-2/32IS MPF	Instant Start	2-lamp	YES
	120V-277V	U-4/32ISE-LBF	Instant Start	4-lamp	YES
		120-4/32IS MPF	Instant Start	4-lamp	No Test
ESPEN		VE232NW HIPHE	Instant Start	2-lamp	YES
		VE232MVHIPLE	Instant Start	2-lamp	
ROBERTSON		ISU232T8120	Instant Start	2-lamp	YES
STANDARD		E232T8IS120-277/N/AS	Instant Start	2-lamp	YES
HOWARD	120-277V	EPH4/32IS/MV/SC/HE	Instant Start	4-lamp	YES
GREEN HILL		GH4P32ISUNV	Instant Start	4-lamp	YES
SZ-TEYUAN	120V-277V	TBE-34CFW	Instant Start	4-lamp	YES
HATCH	120-277V	HL232BIS/UV/HE/W	Instant Start	2-lamp	YES
	120-277V	HL432BIS/UV/HE/W	Instant Start	4-lamp	YES
ESPEN	120-277V	VE232NW HIPHE	Instant Start	2-lamp	YES