# INSTALLATION GUIDE

# Type A+B LED T8 Tube Light

Please keep this Quick Installation Guide for future reference. Modifications to the product void the Warranty. Suitable to replace fluorescent lamps as specified on the product label.

#### WARNING:

a. Risk of fire or electric shock. When working with electronic ballast please check the compatible list first! If you do not find your ballast on the list then please bypass the fixture, or please contact us!

b. Risk of fire or electric shock. LED Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.

c. Risk of fire or electric shock. Install this kit only in the luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.

d. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation

e. To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.

f. To avoid potential fire or shock hazard, do not use this retrofit kit in luminaires employing shunted bi-pin lampholders. Note: Shunted lamp holders are found only in fluorescent luminaires with Instant-Start ballasts. Instant-start ballasts can be identified by the words "Instant Start" or "I.S." marked on the ballast. This designation may be in the form of a statement pertaining to the ballast itself, or may be combined with the marking for the lamps with which the ballast is intended to be used, for example F40T12/IS. For more information, contact the LED luminaire retrofit kit manufacturer.


g. Installers should not disconnect existing wires from lampholder terminals to make new connections at lampholder terminals. Instead installers should cut existing lampholder leads away from the lampholder and make new electrical connections to lampholder lead wires by employing applicable connectors.

h. For a linear tubular LED lamp conversion, there shall be text or a diagram showing how the supply connections were made to the lampholders so the correct connections will be made to the lamp when the lamp is installed or replaced.


i. This retrofit kit is accepted as a component of a luminaire where the suitability of the combination shall be determined by authorities having JURISDICTION.

j.If the tube is installed as Type B, the luminaire, once modified as retrofit fixture, will no longer operate fluorescent lamps.Not suitable for use with Dimmer.

# **TYPE A -Assembly introduction:**



# **Type A-Installation Guide:**




### Instructions

- 1. Switch-off power to the luminaire.
- 2. Remove diffuser ( if provided).
- 3. Remove the existing fluorescent lamps from the luminaire.

4. Install the LED lamp.


Risk of fire. Please note that the tube must be installed corectly. A mark on the end cap shows proper alignment with the sockets. Make sure the mark is matched with the sockets as shown below.



- 5. Install diffuser (if removed in step 2)
- 6. Switch on power to the luminaire.
- 7. Before installation, please check specifications for the most current ballast compatibility list, if no match, please insert LED tubes according to below type B installation instructions.

# **TYPE B -Assembly introduction:**

1. Single side power input – A side



Input voltage:120-277V 50/60Hz

Note:The tube can work with either one side power input or double side power input

# **Type B-Installation Guide:**

## Instructions

1. DISCONNECT POWER OF LUMINAIRE



Luminaire Fluorescent to be replaced

Disconnect power to luminaire or circuit (if possible). Ensure all power is off by using a voltmeter or other method to confirm.


2. REMOVE EXISTING TUBE LAMP(S)

- a. Remove troffer lens, if present.
- b. Remove existing fluorescent by rotating one quarter turn and sliding lamp(s)
- c. Remove ballast cover. (Cover may be secured with screws or tabs)


#### 3. RETROFIT LUMINAIRE

a. Retrofit luminaire with inductive ballast

1)Disconnect the wires between starter and ballast according to the below figure.




2)Connect two wires to branch circuit L and N according to the below figure.




#### b. Retrofit luminaire with electronic ballast


1)Disconnect the wires between tombstone and ballast according to the below figure.




## 2) Connect two wires to branch circuit L and N according to the below figure.



c. Retrofit luminaire with two lamps and one electronic ballast1)Disconnect the wires between tombstone and ballast according to the figure below.




2) Connect two wires to branch circuit L and N according to the figure below.




d. Retrofit luminaire with three lamps and one electronic ballast


1)Disconnect the wires between tombstone and ballast according to the below figure.




### 2) Connect two wires to branch circuit L and N according to the below figure



d. Retrofit luminaire with four lamps and one electronical ballast 1)Disconnect the wires between the tombstone and ballast according to the below figure.



2) Connect two wires to branch circuit L and N according to the below figure.



### 4. INSERT LED TUBES

a. Read label on the LED tube to ensure the power end of LED is aligned with powered tube

socket, then insert LED lamp in the normal way by sliding pins into sockets and rotating a quarter turn until LED tube locks in place. b. LED lamps are now fully installed.

c. Replace troffer lens, if present.

d. After the modification is completed, attach the Replacement Marking and cautionary Label to a visible place on the luminaire and keep it visible after installation.

### 5. RESTORE THE POWER OF LUMINAIRE

Restore power to circuit/luminaire and test light. If necessary, adjust position of LED tube, and enjoy your new LED tube light!